PS-381 Order code

April 9th, 2025

PS381 □ □

① ②


①Instruction manual language

	Contents
Blank	Only Japanese
E	English + Japanese
C	Chinese + Japanese

②Option


	Contents
Blank	Nil
B	With connector for reading ID tag
S	With sensor input connector ・Sensor cable: Standard 5m (or 10m)

※ID reader and ID tag are purchased separately.




PS-381 Standard spec

Connector for reading ID tag



PS-381 With connector for reading ID tag

Sensor input connector



PS-381 With sensor input connector

●Standard accessories

Name
Terminal block cover
Anti-vibration rubber 4pcs
Standard bracket
20-core wiring cable (5m)
Grounding wire
Instruction Manual

●Service parts

Name	Model	Contents
Front panel	PS381-FP	Front panel of PS-381
Power supply unit	PS381-PW	Power supply unit is used inside PS-381

Please contact our sale department for inquiries or information.

SUGIYAMA ELECTRIC SYSTEM INC.
Head Office : 611Man-cho Nakagawa-ku Nagoya Aichi 454-0872 Japan TEL : 81-52-363-0501 E-mail:sales@sugiden.com