PS-581 Order code

October 21st, 2024

PS581 □ □ □ - □

① ② ③ ④

①Instruction manual language

	Contents
Blank	Only Japanese
E	English + Japanese
C	Chinese + Japanese

②Option 1

	Contents
Blank	Nil
L	With connector for link operation

③Option 2

	Contents
Blank	Nil
B	With connector for reading ID tag

※ID reader and ID tag are purchased separately.

④Option 3 sensor cable（L）

	Contents
Blank	5m(Standard)
M10	10m


●Standard accessories

Name	Contents
Terminal block cover	
Anti-vibration rubber 4pcs	
Standard bracket	
12-core wiring cable（5m）	
Grounding wire	
Instruction Manual	
Sensor cable	See ④ for cable length.


●Service parts

Name	Model	Contents
Front panel	PS581-FP	Front panel of PS-581
Power supply unit	PS581-PW	Power supply unit is used inside PS-581

Sensor connector




PS-581 Standard spec




Sensor cable

Connector for link operation



PS-581 With connector for link operation

Connector for reading ID tag



PS-581 With connector for reading ID tag

Please contact our sale department for inquiries or information.

SUGIYAMA ELECTRIC SYSTEM INC.
Head Office : 611Man-cho Nakagawa-ku Nagoya Aichi 454-0872 Japan TEL : 81-52-363-0501 E-mail:sales@sugiden.com