PS-661T/662T Order code

July 26, 2023

With the end of production of the output connector used in PS661/662, the wiring method of the 12P output connector and terminal block will be changed to the terminal block only method.

PS66 □ T □


① ②

① Model


	Contents
1	PS661T(no counter)
2	PS662T(with counter)

② Front panel・Manual language

	Contents
Blank	Japanese panel＋Manual (Japanese)
E	English panel＋Manual (Japanese＋English)
C	Chinese panel＋Manual (Japanese＋Chinese)



PS-661T



PS-662T

● Standard accessories

Name
Spring sensor US-1 ×5 (Blue, White, Yellow, Orange, Pink) US-2 ×1 (Red)
Anti-vibration rubber 4pcs
Standard bracket
12-core wiring cable (5 m)
Earth wire
Instruction Manual

● Service parts

Name	Model	Contents
PS-661 Front panel	PS661-FP	Japanese panel
	PS661E-FP	English panel
	PS661C-FP	Chinese panel
PS-662 Front panel	PS662-FP	Japanese panel
	PS662E-FP	English panel
	PS662C-FP	Chinese panel
Power supply unit	PS66X-PW	Power supply unit is used inside PS-661/662

Please contact our sale department for inquiries or information.

SUGIYAMA ELECTRIC SYSTEM INC.
Head Office:611Man-cho Nakagawa-ku Nagoya Aichi 454-0872 Japan TEL : 81-52-363-0501 E-mail:sales@sugiden.com